


OPERATING MANUAL

RUB AND ABRASION TESTER



©Rhopoint Instruments Ltd.
Rhopoint House • Enviro 21 Park • Queensway Avenue South
St Leonards on Sea • TN38 9AG UK
Web: www.hanatekinstruments.com • Main Office: +44 (0)1424 739 623

Contents

Product Safety.....	2
Equipment.....	3
Package Contents.....	3
Optional Extras.....	4
Operation.....	4
Assembly.....	4
Powering the instrument.....	4
Set Test Conditions.....	5
Selecting test conditions.....	5
Turning on/off the fan.....	11
Sample Preparation.....	5
Sample selection.....	5
Using the sample templates.....	5
Performing a Test.....	6
Selecting test type.....	6
Changing the sample head.....	6
Rubproofness Testing to BS3110.....	7
Abrasion Testing.....	9
Wet Rub Testing.....	9
Selecting test revolutions.....	10
Running a test.....	10
Replacing the pad.....	11
Test Results.....	12
Evaluation of test results.....	12
Service and Repair.....	13
Calibration.....	13
Spares.....	13
Certificate of Conformity.....	14
RoHS and WEEE.....	15

Product Safety

WARNING THE HANATEK RUB TESTER HAS MOVING PARTS WHICH MAY CONSTITUTE A PINCHING RISK FOR HAND/FINGERS AND ENTANGLEMENT RISKS FOR HAIR/CLOTHING.


REASONABLE CARE MUST BE TAKEN AT ALL TIMES – DO NOT TOUCH THE MOVING PARTS DURING OPERATION AND ENSURE HAIR AND CLOTHING ARE KEPT CLEAR.

THE HANATEK RUB TESTER CONTAINS NO USER SERVICEABLE PARTS. DO NOT OPEN THE INSTRUMENT ENCLOSURE- RISK OF ELECTRIC SHOCK OR FIRE.

Equipment

Package Contents

1x	Hanatek Rub and Abrasion Tester	3x	Mains leads – EU/US/UK
1x	Rub Test Sample Template - 115mm	1x	DC power pack
1x	Rub Test Sample Template - 50mm	1x	Knife
1x	Test Weight for 1 P.S.I.	1x	Manual
1x	Standard rub test head	1x	Sample clamping ring
1x	Test Weight for 2 P.S.I. (when combined with weight 1)	1x	Calibration certificate for instrument, templates & weight
1x	Bulls eye spirit level	1x	Spanner



Label	Function
1	Weight platform (for adding supplied test weights)
2	Touch screen display
3	Handle
4	Air feed
5	Removable red sample head
6	Bottom platen
7	Sample clamping ring
8	Operating buttons

Optional Extras



Universal Sample Cutter (RL-A80-005)

Allows for simultaneous cutting of 50mm and 115mm \varnothing samples

Suitable for film and paper-based samples with a thickness between 6 and 250 microns (μm)

Abrasion Tester Head (HAN-B1002RT4HEAD-S)

A more aggressive test, useful for assessing through cure of UV coatings or high abrasion transit testing.

Solvent Resistance Test Head (HAN-B1002RT4HEAD-W)

Used to test the water, detergent, solvent or fat resistance of inks and coatings.

Operation

Assembly

- Remove the instrument from all packaging. Retain the packaging so that the equipment can be returned for calibration and service repairs.
- Place the instrument on a suitable bench and put the supplied bull's eye spirit level on the instrument bed next to the rotating sample holder.
- Check the instrument is level, the bubble should be contained within the circle in the centre of the spirit level. If the weight platform is not level, use the supplied spanner to adjust the feet of the instrument.

Powering the instrument

- Use the supplied mains lead to connect the instrument to a suitable mains supply.
- Switch the instrument on using the button at the rear of the instrument.



Fig 1 – Welcome screen

Set Test Conditions

Selecting test conditions

Select a test condition that is close to the failure point of the material. Increasing the test pressure increases the severity of the test. The failure point can be found by trial and error, several tests should be carried out using increasing weights until marking of the substrate and/or deterioration of the coating is visible.

Test pressure - The weight set provided allows for 3 test pressures:

Pounds / Inch ² (p.s.i.)	kPa Equivalent	Weights
0.5	3.45	None
1.0	6.90	Small
2.0	13.80	Small + Large

- To select the reported test pressure* press the +/- buttons to cycle through the available options (fig 2).
- *Refer to table for mass required to achieve pressure.




Fig 2 – Configuration screen

Sample Preparation

Sample selection

- **Upper sample** - The 50mm diameter sample is typically cut from a sample of printed material. Select an area for testing, it is usual to test areas that are MOST likely to fail; these include any heavy ink build areas or spot colours.
- **Lower sample** - The lower sample is 115mm in diameter - This can either be another sample of the printed material or white paper to see clearly see the ink transference.

Using the sample templates

- Identify the area of the printed sample to be tested.
- Position the supplied template(s) over the area and carefully cut around the template.

Performing a Test

Selecting test type

The instrument can be used with three different sample heads. It is supplied with the foam pad as standard. *(Abrasion/scratch and felt pad heads are optional extras).*

- **Foam Pad** - used for rubproofness testing for BS3110.
- **Abrasion Scratch Test** - a more aggressive test, useful for assessing through cure of UV coatings or high abrasion transit testing.
- **Felt Pad** - used to test the water, detergent, solvent or fat resistance of inks and coatings.

Changing the sample head

- Remove any weights and lift the weight platform and turn the handle so that the head is raised (fig 4).
- Pull down on the red sample head to remove (it is held in place by magnets, fig 5).
- Replace with the required version (fig 6).




Fig 4 – Standard head attached




Fig 5 – Standard head removed




Fig 6 – Replacement head attached

Rubproofness Testing to BS3110

Ensure that *foam* is selected in the test menu and the corresponding sample head is fitted.

Test Options

- **Face to face** - Select an area from the printed material and cut a small and large sample using the sample cutter.
- **Face to reference substrate** - The large sample should be taken from a sheet of high quality white reference material. The smaller sample is taken from the printed material.

Sample Positioning

- Remove the weights from the weight platform and turn the handle to put the instrument into the *up* position (fig 8).



Fig 7 – Weights on weight platform and instrument in down position



Fig 8 – Weights removed from weight platform and instrument in up position

- Remove the sample clamping ring from around the bottom platen.
- Place the large cut printed sample on the bottom platen and replace the clamping ring (fig 9).




Fig 9

- Place the small test sample underneath the foam head with the side to be tested face down and in contact with the large sample (fig 10).




Fig 10

- Lower the sample head using the handle, adjusting the sample so that when fully lowered, the printed sample is exactly covered by the foam pad (fig 11).




Fig 11

- Add required test weights to the weight platform.
- Run Test (*see Running a test*).

Abrasion Testing

Ensure that *scratch* is selected in the test menu and the corresponding sample head is fitted.

Sample Positioning

- Remove the weights from the weight platform and turn the handle to put the instrument into the *up* position (fig 8).
- Remove the clamping ring from around the bottom platen.
- Place the large cut printed sample on the bottom platen and replace the clamping ring (fig 9).
- Lower the abrasion head into contact with the sample using the instrument handle.
- Apply required test weights to the weight platform.
- Run Test (*see Running a test*).

Wet Rub Testing

Ensure that *felt* is selected in the test menu and the corresponding sample head is fitted.

Sample Positioning

- Remove the weights from the weight platform and turn the handle to put the instrument into the *up* position (fig 8).
- Remove the clamping ring from around the bottom platen.
- Place the large cut printed sample on the bottom platen and replace the clamping ring (fig 9).
- Remove the upper measuring head from the instrument (figs 4-6).
- Soak the felt pad head in the required solvent or dose directly onto the felt pad (max dosage 10ml). *Do not apply any liquid directly to the sample under test.*
- Lower the solvent head into contact with the sample using the instrument handle.
- Apply required test weights to the weight platform.
- Run Test (*see Running a test*).

The test can be paused and resumed at any point allowing the reapplication of the liquid. To do this press pause, remove weights, lift handle, remove test head and repeat step 4.

Selecting test revolutions

- To set the number of revolutions, press the *Rev's* button (fig 12) and input the amount of revolutions required (fig13).




Fig 12




Fig 13

Running a test

- Press the on-screen start button (fig 14)
- Use the touch screen or buttons to pause and restart the test.



Fig 14

See 'Test Type' for information on selecting the appropriate test.

Watch the demonstration video here: <https://youtu.be/wBx4i0fjKhU>

Turning on/off the fan

The instrument has a fan to remove paper fibres and debris which act as abrasive agents – not usually required for wet rub resistance test.

- To switch on/off click the button on the test set up menu.



Fig 3 – Reverse of the instrument

Replacing the pad

After every test, the abrasive or felt pad should be checked for damage or excessive coating built up and replaced if necessary. The standard foam pads should both be inspected prior to testing. Damaged pads can lead to uneven pressure distribution across the sample, resulting in incorrect results.



Fig 15 – Test head, scratch pads, foam pads and wet pads

- Peel the old pad off the head, ensuring all adhesive residue is removed.
- Ensure the head is dry and free from contaminants.
- Remove the backing material from the replacement pad and stick in place.

Test Results

Evaluation of test results

Pass/fail of each test is determined visually or by further analysis by using a densitometer, glossmeter or spectrophotometer.

Service and Repair

Calibration

To maintain the optimum performance of this machine Hanatek Instruments recommends an annual recalibration of the equipment.

A full list of service centres can be found on the Hanatek website:

<https://www.hanatekinstruments.com/support/authorised-service-centres/>

Spares

Product	Order Code
Wet rub head (includes 5 pads)	HAN-B1002RT4HEAD-W
Scratch head (includes 5 pads)	HAN-B1002RT4HEAD-S
Pack of 50 scratch pads, self adhesive, 50mm	HAN-H-RT-PAD50S/50
Pack of 50 wet rub pads, self adhesive, 50mm	HAN-H-RT-PAD50W/50
Power pack	HAN-H-PSU RUB 30v
Rub Tester Foam pads 115mm pack of 5	HAN-H-RT-PAD115/5
Rub Tester Foam pads 50mm pack of 10	HAN-H-RT-PAD50/10

For any service or repair quires contact HANATEK instruments:



Tel: +44 (0)1424 739623

Email: support@hanatekinstruments.com

Web Site: www.hanatekinstruments.com

Certificate of Conformity

EC DECLARATION OF CONFORMITY

WE Rhopoint Instruments Ltd, Rhopoint House,
Enviro 21 Park, Queensway Avenue South,
St Leonards on Sea, East Sussex, TN38 9AG

DECLARE UNDER OUR SOLE RESPONSIBILITY THAT THE PRODUCTS

Rhopoint RT4

**TO WHICH THIS DECLARATION RELATES ARE IN CONFORMITY WITH
THE FOLLOWING STANDARDS**

EN 61010-1:2010 Clause 6
EN 61000-4-2:2009
EN 61000-6-3:2007
EN 61000-6-1:2007

FOLLOWING THE PROVISIONS OF DIRECTIVES

2004/108/EC Electromagnetic Compatibility (EMC Directive)

Rhopoint Instruments Ltd
4 August 2011



.....
Tony Burrows, Managing Director



RoHS and WEEE

EU Directive 2002/96/EC on WEEE (Waste Electrical & Electronic Equipment) and RoHS (Restriction of the use of certain Hazardous Substances).

The European Union's Directive on Restriction of the use of certain Hazardous Substances in electrical and electronic equipment (ROHS) defines each of 10 categories of electrical and electronic equipment in Annex I . Category 9 is defined as follows:

9. Monitoring and control instruments
 - Smoke detector
 - Heating regulators
 - Thermostats
 - Measuring, weighing, or adjusting appliances for household or as laboratory equipment
 - Other monitoring and control instruments used in industrial installations (e.g. in control panels).

The RoHS Directive defines the scope of restrictions in Article 2 as follows:

"1. Without prejudice to Article 6, this Directive shall apply to electrical and electronic equipment falling under the categories I, 2, 3, 4, 5, 6, 7 and 10 set out in Annex IA to Directive No 2002/96/EC (WEEE) and to electric light bulbs, and luminaires in households."

This product is supplied as a Monitoring and Control instrument and as such falls within category 9 of the EU directive 2002/96/EC and so is excluded from restrictions under the scope of the RoHS Directive.

The Waste Electrical and Electronic Equipment Directive is intended to reduce the amount of harmful substances that are added to the environment by the inappropriate disposal of these products through municipal waste.

Some of the materials contained in electrical and electronic products can damage the environment and are potentially hazardous to human health; for this reason, the products are marked with the crossed-out wheellie bin symbol which indicates that they must not be disposed of via unsorted municipal waste.

Rhopoint Instruments Ltd have arranged a means for our customers to have products that have reached the end of their useful life safely recycled. We encourage all end users to us at the end of the product's life to return their purchase to us as for recycling as per Article 9 of the WEEE Directive.

Please contact us on +44 (0) 1424-739622 and we will advise on the process for returning these waste products so we can all contribute to the safe recycling of these materials.